

Installation Instructions

1. Thoroughly clean the vacuum-head with a non-oil-base cleaning solution. Clean again with the provided alcohol wipes.

Note: Dirt will prevent Velcro® adhesive from adhering well.

2. Peel plastic backing from Velcro® and attach strips directly to the hard plastic frame of the vacuum-head as shown in Figure 1.

Note: Do not attach Velcro® to vacuum manufacturer's vinyl bumper.

3. For best results, install DuraBumper™ 24-hours after attaching Velcro®.

Note: Adhesive reaches maximum strength 24-hours after Velcro® installation.

4. Center, stretch and attach the bumper as shown in Figures 2 and 3.
 - a. Bumper must completely cover the Velcro® to prevent dirt from attaching to adhesive.
 - b. Bumper must not hang below the vacuum-head, as this will impede the vacuum's performance.
 - c. Do not cover vacuum's ventilation system.
 - d. If bumper is too long, adjust by removing end-segments. Using sharp scissors, cut behind the seam to prevent fabric from gapping and fraying.

Care Instructions

Remove dust and debris with a lint-roller. Machine washable; air dry.



DuraBumper.com • Service@DuraBumper.com • (480) 699-1172

10645 N. Tatum Blvd., Suite 200-377, Phoenix, AZ 85028-3068



Figure 1



Figure 2



Figure 3