

To Start Vacuuming



- 1** Open the door and pull out the amount of hose you need. You will feel the hose stop when you get to the end. If the hose comes completely out of the wall, simply reinsert the hose several inches back into the inlet.
- 2** Place the locking mechanism into the locked position. Note: The locking mechanism prevents the hose from retracting while you vacuum. If you wish to pull out more hose, turn off your vacuum before moving from the locked position.
- 3** Two ways to turn the vacuum on and off: **Option 1:** Use the switch at the inlet. **Option 2:** Use the RF handle.



When You're Finished Vacuuming

- 1** With the vacuum still running and all attachments disconnected, bring all of the hose back to the base of the inlet.
- 2** Move the locking mechanism to the unlocked position.
- 3** Regulate the retraction speed carefully by placing your fingers or the palm of your hand over the end of the hose. Control the speed until the hose has retracted itself completely into the inlet.
- 4** If you turn the unit on with the switch, you must turn the unit off with the switch. If you turn the unit on with the RF handle, you must turn the unit off with the RF handle.
- 5** **Be sure the locking mechanism is in the unlocked position** (the door will not close properly if it is locked). Close the door.

